OPC DA Architecture

Single OPC DA Server

PC

OR

WIN-911

OR

Supervisory Network

**OPC DA
Server**

WIN-911 can be installed on the OPC DA server or any PC with network access to the OPC DA server.

Field Network

OPC
FOUNDATION

OPC DA Architecture

Two OPC DA Servers with a single WIN-911 system

PC

PC

Supervisory Network

WIN-911 can be installed on the OPC DA server or any PC with network access to the OPC DA servers.

**OPC DA
Server 1**

**OPC DA
Server 2**

WIN-911

A

B

1 additional node

Field Network